KOMPATIBILITÄTSLISTE

EPSON

DRUCKERTYP

	S020089 Color Ink Cartridge	S020093 Black Ink Cartridge	S020108 Black Ink Cartridge	S020110 Color Ink Cartridge	S020118 Black Ink Cartridge	S020122 Yellow Ink Cartridge	S020126 Magenta Ink Cartridge	S020130 Cyan Ink Cartridge	S020143 Mag/light Mag. Ink Cartridge	S020147Cyan/light Cyan Ink Cartridge	S020187 Black Ink Cartridge	S020189 Black Ink Cartridge	S020191 Color Ink Cartridge	S020193 Color Ink Cartridge	S020206 2xS020093 Ink Cartridge	S020207 2xS020108 Ink Cartridge	S020208 2xS020187 Ink Cartridge	S020209 2xS020189 Ink Cartridge	T001011 Color Ink Cartridge	T003011 Black Ink Cartridge	T003012 2xT003011 Ink Cartridge	T005011 Color Ink Cartridge	T007401 Black Ink Cartridge	T007402 2xT007401 Ink Cartridge	T008401 Color Ink Cartridge	T009401 Color Ink Cartridge	T010401 1/2xT007401 Ink Cartridge	T013401 Black Ink Cartridge	T013402 2xT013401 Ink Cartridge	T014401 Color Ink Cartridge	T015401 Black Ink Cartridge	T016401 Color Ink Cartridge	T017401 Black Ink Cartridge	T017402 2xT017401 Ink Cartridge	T018401 Color Ink Cartridge	T019401 Black Ink Cartridge	T019402 2xT019401 Ink Cartridge	T020401 Color Ink Cartridge	T026401 Black Ink Cartridge	T027401 Color Ink Cartridge	T028401 Black Ink Cartridge	T029401 Color Ink Cartridge	T032140 Black Ink Cartridge	T032240 Cyan Ink Cartridge	T032340 Magenta Ink Cartridge	T032440 Yellow Ink Cartridge	T032540 Triple pack Ink Cartridge	C13T033140 Black Ink Cartridge	C13T033240 Cyan Ink Cartridge	C13T036140 Black Ink Cartridge	C13T037040 Color Ink Cartridge
EPSON Stylus Color 440											●		●				●																										
EPSON Stylus Color 460											●		●				●																										
EPSON Stylus Color 480																													●	●	●														
EPSON Stylus Color 480SXU																													●	●	●														
EPSON Stylus Color 580																													●	●	●														
EPSON Stylus C20 ux/sx																													●	●	●														
EPSON Stylus C40 ux																													●	●	●														
EPSON Stylus C42																																											●	●
EPSON Stylus Color 640											●		●				●																										
EPSON Stylus Color 660											●		●				●																										
EPSON Stylus Color 670											●		●				●																										
EPSON Stylus Color 680/5																																	●	●	●										
EPSON Stylus Color 740												●	●					●																										
EPSON Stylus Color 760												●	●					●																										
EPSON Stylus Color 800	●		●														●																										
EPSON Stylus Color 850	●		●														●																										
EPSON Stylus Color 860												●	●					●																										
EPSON Stylus Color 880																																				●	●	●							
EPSON Stylus Color 900																					●	●	●																				
EPSON Stylus Color 980																					●	●	●																				
EPSON Stylus C60																																							●	●				
EPSON Stylus C70																																								●	●	●	●	
EPSON Stylus C80																																								●	●	●	●	
EPSON Stylus Photo 810																																						●	●					
EPSON Stylus Color 1160												●	●					●																										
EPSON Stylus Color 1520	●		●													●																										
EPSON Stylus Color 3000					●	●	●	●																																				
EPSON Stylus PRO 5000					●	●			●	●																																		
EPSON Stylus Photo		●		●											●																												
EPSON Stylus Photo 700		●		●											●																												
EPSON Stylus Photo 750											●			●			●																										
EPSON Stylus Photo 790																							●	●	●		●																
EPSON Stylus Photo 870/875DC																							●	●	●		●																
EPSON Stylus Photo 890																							●	●	●		●																
EPSON Stylus Photo 895																							●	●	●		●																
EPSON Stylus Photo 950																																											●	●	
EPSON Stylus Photo 1200											●						●		●																										
EPSON Stylus Photo 1270																							●	●			●	●																
EPSON Stylus Photo 1290											●						●		●																										
EPSON Stylus Photo Ex		●		●											●																												
EPSON Stylus Photo 2000P																																	●	●										
EPSON Stylus Scan 2000/2500												●	●					●																										